

Assembly instructions for flush rose EPL PASSAGE

Flat roses surface mounting (round or square)

1.) Drill a 19mm hole in the door to allow the spindle to be put through the lock follower (1).

2.) Put the drilling template onto the spindle and mark the hole centers on both sides of the door.

3.) Remove the spindle (1) and drill 8mm holes at the marked points from both sides until you reach the lock case.

ATTENTION! Do not drill through the lock case!

4.) If necessary, remove the metal bushings (3) from the rose by using the assembling aid.

Fix the rose mounting plates (4) on the door and secure with the M4 bolt through fixings (5) incl. metal lugs (6).
For door thickness 38 mm – approx. 48 mm

5.) Press the lever handle cover (7) onto the mounting plate (4), so that the parts click into place.
Note the cutout on the bottom of the cover should align with the tab on the mounting plate.

6.) Install the metal locking ring (3) into the clip-on rose and tighten by using the assembling aid (M).

7.) Insert the spindle (1) into the lock follower and center it.


ATTENTION: Insert the spindle in such a way that the point of the grub screw can pierce the thinnest side.

8.) Put one lever handle (3) with the plastic guide ring (10) in the lever rose and pay attention that the spindle stays centered.

9.) Tighten the grub screw (11) a bit so that the spindle cannot shift anymore. Mount the other lever handle (9) with the plastic guide ring (10) and tighten the grub screws (11) while pressing both handles together.

10.) Ensure that the grub screws (11) are piercing the spindle at the thinnest side.

11.) Test the function of the levers before closing the door.



KARCHER
— **DESIGN**

KARCHER DESIGN NA
235 W. Paul Ave
Clovis, CA 93612-0250
United States of America

Limited Warranty – USA & Canada Only

Karcher Design warrants to the original purchaser and first consumer owner that its products shall be free from defects in material or workmanship for 2 years after purchase.

Subject to the conditions stated below, Karcher Design shall repair or replace (at our sole discretion) any defective product at no further charge.

This warranty is valid only for the original purchaser and first consumer owner and is not transferable.

This warranty *only* applies to products purchased directly from an authorized dealer of Karcher Design products. Our [website](#) contains a list of authorized dealers. You may be asked for proof of purchase, so please retain your receipt.

To obtain warranty service, please contact an authorized reseller dealer directly. Do not contact Karcher Design directly with warranty questions.

This warranty does not apply to ordinary wear and tear or to damage caused by conditions beyond Karcher Design's control, including but not limited to accidents, lack of reasonable care, weather conditions, improper installation or maintenance, alteration, or abuse. **In particular, this warranty does not apply to products that are not intended to be used outdoors (including products made out of wood, leather, carbon, glass, laminate, and satin nickel) that are in fact used outdoors.**

THE REMEDIES DESCRIBED ABOVE ARE YOUR SOLE AND EXCLUSIVE REMEDIES, AND CONSTITUTE KARCHER DESIGN'S ENTIRE LIABILITY FOR ANY BREACH OF THIS LIMITED WARRANTY. KARCHER DESIGN EXCLUDES AND EXPRESSLY DISCLAIMS LIABILITY FOR ANY CONSEQUENTIAL, INDIRECT, INCIDENTAL OR SPECIAL DAMAGES OF ANY NATURE ARISING OUT OF THE SALE, INSTALLATION, MAINTENANCE, USE OR FAILURE OF ANY KARCHER DESIGN PRODUCT, INCLUDING BUT NOT LIMITED TO LOSS OF PROFITS, PROPERTY DAMAGE, DAMAGES TO BUSINESS OR BUSINESS RELATIONS OR DAMAGES FOR LOSS OF OPERATION. IN ALL EVENTS KARCHER DESIGN'S LIABILITY WILL BE CAPPED AT THE PURCHASE PRICE PAID FOR THE PRODUCT.

Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

No representative or employee of Karcher Design is authorized to make any modification or addition to this warranty.

Karcher Design NA, LLC

235 W. Paul Ave
Clovis, CA 93612-0250
Office: 425-440-0708